

# De-Winterizing

De-winterizing is a fairly simple routine procedure which you can do on your own. Follow these steps.

1) Make sure your low point drain caps are tightly screwed on both the hot & cold (the 1 red & 1 white pen hoses located under the trailer hanging near the Rinnai tankless heater). East Coast usually puts back on after they “winterize,” but it’s smart to confirm they are back on after they do so.

2) Connect your hose to the white pen supply line under the trailer to the low-point drain plugs described above. Then connect the hose to the other end, which is of course your spigot outside at the utility box/pole behind your trailer in the right rear corner of your site.

3) Run hot & cold water through your sinks & showers until all the pink anti-freeze is back to clear water (no more pink).

4) If your fridge has an ice maker, make sure the supply valve is open behind the fridge down at the floor coming through the wall & connected to your fridge around back of the fridge down at the bottom. Then, run a couple cycles of ice through the ice maker until they’re not pink (maybe 3 cycles to be safe before you use the ice cubes).