



MJ5PM8000



5 Panel Mirror Installation Instructions

What's in the box:

- 5 Panel Mirror
- 2 x Bracket
- 2 x Angle Bracket
- 2 x Knob
- 2 x Short M8 Bolt
- 1 x Long M8 Bolt
- 4 x M8 Lock Washer
- 4 x M8 Hex Nut
- 4 x Phillips Head Screw

1. Use Angle Bracket as guide to mark pilot holes for Screws.
2. Drill two small (7/64") pilot holes in car frame just below canopy.
Repeat steps 1 and 2 on opposite side of car.



3. Use Two Screws to attach Angle Bracket to car frame.



4. Attach slide bracket to angle bracket. Insert small carriage bolt through slide bracket and angle bracket. Place lock washer on end of bolt. Thread nut as shown and tighten.

Repeat steps 3 and 4 on opposite side of car.



5. Insert large carriage bolt through hole at end of mirror as shown.



6. Put end of bolt through slide bracket. Place lock washer through end of bolt. Thread knob onto bolt and and tighten.

Repeat steps 5 and 6 on opposite side of car.



Assembled and Installed 5 Panel Mirror.

