



## PRECEDENT CLAYS BASKET INSTALLATION INSTRUCTIONS

04-009

### INCLUDED:

MADJAX CLAYS BASKET  
BRACKETS  
HARDWARE PACK



**1**  
Remove bolt cover and bolts  
from front struts. Retain all  
factory hardware. You will  
need it later.



**2**  
Using retained factory hardware,  
attach brackets to front struts.  
Tighten bolts.



Attach clays basket to brackets on both sides using hardware pack.

## PRECEDENT CLAYS BASKET HARDWARE PACKS

### HARDWARE PACK 1

- (4) 10MM X 40MM SHOULDER HEX BOLTS
- (8) 10MM X 20MM X 2MM WASHERS
- (4) 10MM ANTI-SLIP NUTS

