



## EZ-GO TXT BRUSH GUARD INSTALLATION INSTRUCTIONS

MJBG220B (BLACK)    MJBG2020S (STAINLESS)



### INCLUDED:

MADJAX EZ-GO TXT BRUSH GUARD

1

Remove bolts from front struts.  
Retain all factory hardware.  
You will need it later to attach  
the brushguard to the cart.



Using retained factory hardware,  
attach brush guard to front struts.  
Tighten bolts.

2