



1. Position Light Bar on front center of vehicle canopy. Using holes on base of Light Bar as a guide, drill four 5/16" holes in canopy.

2. Using location of the light bar wire housing, drill a 1/2" hole in canopy. String wire loom through hole and run down vehicle strut.

3. Attach Light Bar to vehicle canopy using Pushpins.





4. Run wire loom behind dash assembly.

5.Drill hole in dash slightly larger than switch and install switch. Run black wire to a good ground (12 volt)\* † and the red wire to a 12 volt\* source.



\*Wiring to source other than 12 volts will damage light. <sup>†</sup>Kit may require 12 volt reducer.