

W-5000 2K WHITE TOPCOAT



2 Hours

- + 2k Standard : Add 5% W-350 Catayst
- + Excellent Coverage-1 coat coverage
- + Excellent Sanding

2K Self-Seal Finish Cycle



Wire Brush unfinished substrate



Apply W-5000 2K White Topcoat by HVLP 3 wet mils max Reduce 40-50% Water Retard 5-10% W-226 Wipe coating into open-pores and remove excess coating Let dry 1 hour



Scuff sand surface with 320 sandpaper



Apply W-5000 2K White Topcoat by HVLP 3-4 wet mils max Reduce 30% Water Retard 5% W-226 Let dry 1 hour



Scuff sand surface with 320 sandpaper



Apply W-5000 2K White Topcoat by HVLP 3-4 wet mils max Reduce 30% Water Retard 5% W-226



hartleyitalia.com