See us in Section 47 of the BLC!

Conowingo Models

CONOWINGOMODELS.COM

Nothing looks as good as wood!

Conowingo Models

About Me – Chris Coarse



Conowingomodels.com

- Air National Guard C-130H Loadmaster
- Married with two daughters
- Residing in Conowingo, MD 3 miles from the dam
- Tyco Silver Streak train set as a kic
- Returned to model railroading in 2012 thanks to Polar Express
- Conowingo Models was started in 2019
- Logo is Pentaquod from James Michener's novel "Chesapeake which references Conowingo
 - Will eventually model the Rutland Railroad







RUTLAND



Item

WHAT YOU WILL NEED TO BRING WITH YOU

ALL TOOLS, GLUE AND PAINT PROVIDED Paint is only needed for touch-ups





The structure you are about to build is semi-fictional.

Conowingo Models

CONOWINGOMODELS.COM

The concept has been done many times, however the 24-Foot Boxcar is a conglomeration of several boxcar designs

Included is signage for an ice cream shop and a coffee shop








1. Cut the stripwood

Stripwood Cut Chart

<u>Size</u>	<u>Color</u>	<u>Length</u>	<u>Quantity</u>	<u>Nomenclature</u>
1/8 inch	Black	1.25 inches	4	Base Supports
1/8 inch	Black	.7 inches	2	Deck Supports
1/16 inch	Brown	1.58 inches	2	Door Track
1/16 inch	Brown	1.78 inches	1	Step Base
1/32 x 3/32	Stain Grey	.83 inches	7	Decking
1/8 inch	None	1 inch	12	Bracing
1/8 inch	None	3 inches	2	Bracing



2. Brace the walls



Do Not brace all the way to the edges- Doing so would prevent the walls from fitting together.



3. Assemble the windows and doors

- Glue acetate into the windows x3
- Glue the doors into the doorways x2

Glue the slider window into the desired location on the window








4. Assemble the building halves

Note the tenon on the top of the end wall

- Glue the corners together so that the tenon fits in the notch
 - Ensure there is no end bulging out

Repeat for the other hal






5. Assemble the building

 Take two halves and glue the corners together so that the tenons fit in the notches

Ensure there is no end bulging out

- Hold square until tacky

- Add the 1/8 base supports as shown below. This should hold the building square






6. Prepping the Roof

Cut the two pieces that look like this from the roof walk. These are the roof steps. Cut each down so you have a total of six pieces

- Bend the roof as shown.
- Glue the roof into position on the boxcar as evenly as you can. Note the flat spot.
- Apply the roof walks as shown





Conowingo Models Repurposed 24-Foot Boxcar Clinic <u>6Aish. Roof Details</u>

- If you build the roof at home, you have options –

- The roof will either be in really bad shape or in great shape as it was replaced at one time.
- You could install a tar paper roof. Look up Jason Jensen Trains episode 010 if you would like some great instructions on how to do this.
- You could take a razor saw and rough up the roof.
- Patches are easy to do. Simply cut out a piece of cardstock in the size and shape you desire, paint it, add nail holes with a hobby knife and glue in place.
- Also you can put a much or as little of the roof walks on the roof as they want.




-

Conowingo Models Repurposed 24-Foot Boxcar Clinic 7. Building The Sign

Cut out the frame for the sign and the center support

- DO NOT CUT OFF THE END SUPPORTS
- Carefully deepen the grooves for the end supports. You want them to bend
- Bend the two supports at a 90° angle
- Glue the center support in the middle, also at a 90° angle.





8. Adding Signage



Decide which of the signs you would like to use for your shop LOCOMOTION COFFEE CAR Antendam 1 (5) Carpendine 33 50 Carpendine 33 50 Carpendine 35 55 Signature Corre Come Come Corre Come Come Corre Come Corre Come Corre Come Come





- Cut the respective sign and menu from the paper sheet Make the cut a little bit bigger than the outline
- Add a layer of glue to the white side of the sign board and menu
- Carefully apply the sign and menu to their respective boards, ensuring they are level and centered
- Glue the sign to the sign frame




9. Building The Deck


Glue the 1/32 x 3/32 deck boards to the deck base as shown. Reserve one for the step.

Space them as evenly as possible and ensure there is a slight overhan

on each side.

- Glue the 1/8-inch deck supports into position
- Glue the 1/16-inch step base into position
- Glue the last piece of 1/32 x 3/32 into place







Conowingo Models Repurposed 24-Foot Boxcar Clinic <u>10. Details</u>

Install the door tracks on both sides as shown below. Note the left side of the door tracks lines up with the scribe line because of the window clearance

- Glue the window into place
- Glue the sign and menu into place
- Glue the deck into place. We matched up the right edge of the deck with the right edge of the door frame
- Decide where you want the smoke jack and poke a hole there with your knife
- Glue the smoke jack into place









11. Finishing Touches





- Do paint touch-ups

- Weather as appropriate
- The grabirons were "removed" when this was converted from a boxcar into a shop. You could-
- 1. Add wire grabirons some were "broken off", so you will have to add the holes
- 2. Weather with black paint to simulate rot.
- 3. Weather with orange paint to simulate rust. (like we did)



Conowingo Models

Conowingo Models Repurposed 24-Foot Boxcar Clinic

(3)

Shank yo

Would you like some Conowingo Models Swag?

Scan the QR code to see available t-shirts, hats, sweatshirts, etc.

One of these days... I'm coming to a train show.... If I can stay awake that long...

