

ARCANE P²

ELECTRICAL ROUTING



**GROUND THE HARNESS
TO THE SEAT ANCHOR BOLT
MAKE SURE ITS A GOOD GROUND!**

**CONNECT THE TWO
PUMP POWER EYELETS
TWO PUMP GROUND EYELETS
AND FUEL LEVEL WIRES TO THE HAT**

**PLUG AND PLAY TO FACTORY
PUMP CONNECTOR FOR
FUEL LEVEL AND OEM
LIKE FUEL PRIMING**

**PASS THE FIREWALL RIGHT IN FRONT OF THE
BODY CONTROL MODULE IN THE PASSENGER
KICK PANEL. THE FUSES WILL STAY JUST INSIDE**

**ROUTE POWER WIRES TO
BATTERY JUNCTION BOX
AND PLACE EYELET UNDER EXISTING NUT**

JN2NING