

CAN AM RYKER ZSW FRONT GRILLE 2018-2019 MODELS

INSTALLATION INSTRUCTIONS

23815 HICKORY PASS SAN ANTONIO, TX 78264 SALES@ZARATESTEELWORKS.COM WWW.ZARATESTEELWORKS.COM PHONE: 210-765-0974



PLEASE READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION

KIT INCLUDES

QTY- 1 Front Ryker Grille

QTY- 2 Stainless Steel Bolts (1/2 Long-Use on bottom)

QTY- 2 Stainless Steel Bolts (3/4 Long-Use on top)

QTY- 4 Washers

QTY- 4 Nuts

TOOLS NEEDED FOR INSTALLATION

- Power Drill
- 13/64 Drill Bit
- Socket Set
- Wrench set

INSTRUCTIONS APPLY FOR THE FOLLOWING GRILLES:

- TRIO
- HONEYCOMB
- SPEEDSTER
- FANG GRILLE
- CUSTOM

PAGE 1 REV2FEB 2020



Remove the two lower bolts that secure the front bumper cover .



Once the 2 lower bolts are removed proceed to removing the hood & front end cover.



Once the front cover has been removed, begin to line up your grille with the front bumper.

IMPORTANT: Grille may need to be flexed a bit to contour to the factory grille.




Ensure the lower tab sits flush with the inner edge of the grille. You may need an extra hand to help flex the grille to the contour of the factory front end so the tab sits flush.





Now that the grille is lined up, begin to mark the bottom holes first. Next mark the top holes.






Note: Use 1/2 inch long bolts for the bottom.



Note: Take your time as you are going to have to drill at a slight angle and don't want to drill a bigger hole then needed.









8

Now that the grille is installed and all the nuts and bolts are secured begin to re-install the front end back onto the Ryker and ensure everything is secured.

Enjoy your new grille!



THANK YOUFOR YOUR PURCHASE!
FOLLOW US ON FACEBOOK & INSTAGRAM
TO SEE OUR LATEST PRODUCTS.
TAGUS IN WITH YOUR FINISHED INSTALLED
PICTURES!



WWW.ZARATESTEELWORKS.COM