



23815 HICKORY PASS SAN ANTONIO, TX 78264

SALES@ZARATESTEELWORKS.COM

WWW.ZARATESTEELWORKS.COM | PHONE: 210-765-0974

## CAN-AM SPYDER F3 FOOT RESTS

2015-2019 SPYDER

F3-T & F3 LIMITED MODELS

### INSTALLATION INSTRUCTIONS



**! PLEASE READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION**

#### KIT INCLUDES

QTY- 1 Left Side Foot Rest  
QTY- 1 Right Side Foot Rest  
QTY- 8 Stainless Steel Allen Head Bolts  
QTY- 8 Stainless Steel Nylon Locking Nuts

#### TOOLS NEEDED FOR INSTALLATION

-Allen Wrench Key Set  
-Flat Head Screw Driver  
-Power Drill  
-15/64 Drill Bit

#### DISCLAIMER

ALL ZARATE STEEL WORKS PRODUCTS ARE MADE FOR  
OFF ROAD USE ONLY

Zarate Steel Works® is a Registered Trademarked and is registered in the U.S. Patent and Trademark Office.


PAGE 1

REV1 JAN 15 2020



1

Remove the 4 factory allen head bolts from each foot rest and discard factory bolts as you will not be using them for the install.




2

Remove the rubber foot pad after removing the 4 factory bolts.




3

Flip over the rubber foot pad and using the 15/64 drill bit, drill through each factory hole as shown in Figure 1. Then place each rubber foot pad back onto the bike.



4

Using the supplied hardware place the new foot rest on top of the rubber foot pad aligning to the holes. Insert and push each new bolt through the hole.







- 5 After all 4 bolts have been pushed through start hand tightening the nuts at the bottom. The holes at the bottom are too small to fit a socket in therefore use a flat head screwdriver to put tension on the nut so it can be tightened with the allen wrench as shown in Figure 2.



The installation is now completed!



THANK YOU FOR YOUR PURCHASE!  
FOLLOW US ON FACEBOOK & INSTAGRAM  
TO SEE OUR LATEST PRODUCTS.  
TAG US IN WITH YOUR FINISHED INSTALLED  
PICTURES FOR A CHANCE TO WIN FREE PRODUCTS!

