



23815 HICKORY PASS SAN ANTONIO, TX 78264

SALES@ZARATESTEELWORKS.COM

WWW.ZARATESTEELWORKS.COM | PHONE: 888-552-9272

# SS FRONT BUMPER LOWER ACCENT SKID PLATE 2020-2021 SLINGSHOT MODELS INSTALLATION INSTRUCTIONS



## KIT INCLUDES

QTY- 1 Front Bumper Lower Accent Skid Plate

Stainless Steel Hardware:

QTY- 4 1/4" x 3/4" Inch Bolts F19452

QTY- 4 1/4" Locking nuts F12190

QTY- 4 1/4" Washers F113873

QTY- 3 3/16" x 3/4 Inch Bolts F13972

QTY- 3 3/16" Locking nuts F114752

QTY- 6 3/16" Washers (Use on top and bottom for install) F117227

## TOOLS NEEDED FOR INSTALLATION

- Power Drill
- 1/4" Drill Bit
- 1/4" Driver Bit
- 3/16" Drill Bit
- 3/16" Driver Bit
- Marker

For any questions during the installation you can  
call or text 210.765.0974 or email us at [sales@zarateteelworks.com](mailto:sales@zarateteelworks.com)



1



To install, align the Front Lower Accent Skid Plate to the bike and mark all the holes for drilling reference.

2

Next begin to drill the markings, the first set of holes to be drilled out are the (4) 1/4 inch holes towards the front of the bike. Then drill the (3) 3/16 smaller holes towards the back by the factory air dam.



3

Lastly, install the (4) 1/4 inch bolts towards the front of the bike. Then install the (3) 3/16 smaller bolts towards the back by the factory air dam, for the 3/16 bolts use a bottom and top washer.



**The installation is now complete!**

THANK YOU FOR YOUR PURCHASE!  
FOLLOW US ON FACEBOOK & INSTAGRAM  
TO SEE OUR LATEST PRODUCTS.  
TAG US IN WITH YOUR FINISHED INSTALLED  
PICTURES!

