



SS FRONT END BUMPER SPLITTERS 2015-2020 SLINGSHOT MODELS INSTALLATION INSTRUCTIONS

23815 HICKORY PASS SAN ANTONIO, TX 78264

SALES@ZARATESTEELWORKS.COM

WWW.ZARATESTEELWORKS.COM | PHONE: 210-765-0974



! PLEASE READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION

KIT INCLUDES

QTY- 2 Front Bumper Splitters
QTY- 6 Stainless Steel 1/4 inch Bolts
QTY- 6 Stainless Steel 1/4 Washers
QTY- 6 Stainless Steel Nylon Nuts

TOOLS NEEDED FOR INSTALLATION

-Drill and 1/4 drill bit
-7/16 Wrench
-5/32 Allen Wrench



- 1 Place the front splitter under the front of the Slingshot as shown below for test fitting.



- 2 Once you have aligned the splitter, begin marking the drill holes. Start with the hole towards the center of the Slingshot.



- 3 After you have marked the holes begin to drill them using a 1/4 drill bit.

! IMPORTANT: Drill all the holes in the center of the bottom lip as shown .



- 4 After the holes are drilled install the hardware provided. Place the washer on the top side of the inner lip under the nut.



Your installation is now complete! Enjoy your new accessories!



Like us