



## **Installation instructions for Composite Fencing with concrete posts**

Every fencing kit is supplied with 2 vertical composite U channel inserts, 2 horizontal composite U channel inserts and the required amount of boards.

2 x 1830mm horizontal inserts (one with 5 holes for the top)

2 x 1720mm vertical inserts

Screws for securing the top composite U channel to the top fence board if required

1. Place the 1830mm length of composite U channel insert on the ground or on top of the gravel board, making sure you are using the composite U channel insert with no holes in it. (The 1830mm composite U channel insert with 5 holes in is for the top)
2. Place the 1720mm composite U channel insert into each of the slots on the concrete post you may require to cut these to suit the height of the fencing that you require
3. Slide in the required amount of composite fence boards to achieve the height required
4. Place the top composite U channel insert on top of the last composite fence board and this should fit on top of the composite U channel on each side
5. Using the Torx driver screw in the black screws on top of the composite U channel into the top composite fence board. If you wish to secure the top board, you can use an adhesive silicon in the top composite U channel insert and also the composite U channel insert that fits into the concrete posts
6. Please note that you may need to trim the composite fence boards if your concrete posts are not vertical and out of square