




**Chrysler CDR 21.4 Coverage Feb 2022 (see help file for Fiat & Lancia)**

Last 3 digits of Bosch CDR DTM adapter/cable number :		2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020	2021	2022
Chrysler	200	Console, aft of shifter						790/516		387/516		387/785							
Chrysler	300	Center stack	226 <sup>5,5</sup>	228 <sup>5</sup>				387/598											
Chrysler	Aspen	Console, aft of		226 <sup>4</sup>	226														
Chrysler	Cirrus (not sold in US)	see help file						387/516 <sup>8</sup>											
Chrysler	Grand Caravn Voygr	Center stack						387/385 <sup>8</sup>										387/785	
Chrysler	Pacifica	Center stack			228 <sup>5</sup>									387/785					
Chrysler	PT Cruiser	Console, fwd of		226 <sup>7</sup>	228 <sup>5</sup>														
Chrysler	Sebring	Console, aft of		226 <sup>4</sup>	226			387/516 <sup>8</sup>											
Chrysler	Town & Country	Center stack					385 <sup>6</sup>	387/385 <sup>8</sup>		387/785									
Dodge	Avenger	Console, aft of			226			387/516 <sup>8</sup>	387/790/516	387/516									
Dodge	Caliber	Center stack		226 <sup>4</sup>	226			387/516 <sup>8</sup>	387/790/516										
Dodge	Caravan	Center stack				385 <sup>6</sup>		387/385 <sup>8</sup>		387/785									
Dodge	Challenger	Center stack			228														
Dodge	Charger	Center stack		226 <sup>5,5</sup>	228 <sup>5</sup>					387/228 <sup>10</sup>	387/228		387/598						
Dodge	Dakota/Raider	Center stack		228 <sup>3</sup>					228	Mex Only									
Dodge	Dart	Center Stack								387/785									
Dodge	Durango	Console, aft	226 <sup>2,4</sup>	226 <sup>2,4</sup>	226 <sup>2,4</sup>	226 <sup>2</sup>	226 <sup>2</sup>	387/228 <sup>10</sup>	387/228		387/598								
Dodge	Journey	Console, fwd of shifter					385	387/385 <sup>8</sup>		387/385	+516PPT				387/821				
Dodge	Magnum	Center stack		228 <sup>3,8</sup>	228 <sup>5</sup>														
Dodge	Nitro	Console, aft of		227 <sup>4</sup>	227			387/516 <sup>8</sup>											
Dodge/Ram	Promaster City	FW of shifter										387/802	+ 709 DLC Adapter						
Dodge/Ram	Promaster (Big Van)	Center Tunnel										387/829 new 17_4	+ 709 DLC Adapter						
Dodge/Ram	Ram Cab Chassis	CF Seat/console		226 <sup>4</sup>				387/453 <sup>8</sup>			387/785								
Dodge/Ram	Ram Pickup (25-3500)	CF Seat/console		226 <sup>4</sup>		226 <sup>9</sup>		387/453 <sup>9</sup>											
Dodge/Ram	Ram Pickup (1500)	CF Seat/console		226 <sup>4</sup>	226	453 <sup>8</sup>		387/453 <sup>8</sup>	387/453										
Dodge/Ram	Ram Van	Center Stack								387/785									
Dodge/SRT	Viper	Center Stack								387/785									

The source data for this chart is the Bosch CDR help file for Version 21.0 as of Dec Feb 2021 & Chrysler  
 Always consult the latest help file for the most accurate coverage  
 Superscripts defined:

- 2 If equipped with side airbags (some without side bags might be read also)
- 3 Some 2006 models may contain EDR data not read by CDR tool
- 4 2006-7 Records in **Frontal Deployments Only** Any deployment
- 5 Wait 1 minute after powering up to read module
- 6 Some early 2008 modules may not read thru DLC, must be direct to module
- 7 Some 2007 PT Cruisers may contain EDR data not read by CDR tool
- 8 90% 563 intent, records in Non-deploy events
- 9 Some 2009 RAM 2500 may need 453 cable
- 10 Some early production 2011 Challenger, Durango, & Grand Cherokee may not have Delta V

Copyright 2021  
 Ruth Consulting LLC  
 Authorized for use by IPTM & SAE  
 EDR stored but not CDR retrieble  
 EDR stored, may not be CDR retrievable  
 563 Intent  
 + Running Change mid model year

\* Requires DLC 3 adapter for DLC readouts

2017+ New Models with Wheel Speed & Brake Pressure