

Iron-On Instructions:



- Pre-wash all materials (do not use fabric softener).
- Preheat iron to medium heat (no steam).
- Remove the PVC patch from its Velcro backing.
- Place the clear adhesive side to the garment side of the Velcro, leaving the paper liner facing up.
- Press the iron firmly onto the paper liner for 2 seconds at a time, repeating as needed until the entire surface is bonded.
 - Be cautious—adhesive may slide if overheated!
- Allow to cool completely.
- Peel off the paper liner.
- Position the prepared Velcro on the garment/item as desired.
- Flip the garment over and iron from the reverse side, applying firm pressure for 8 seconds.
- Repeat until the entire area is securely bonded.
- Let cool before attaching the PVC patch to the Velcro.
- Wait 48 hours before washing.
- Wash on delicate using cold or warm water (not hot).
- Always remove patch from Velcro before washing.
- Tumble dry low. Do not dry clean.

⚠ Important:

High heat can weaken the adhesive and cause the patch to shift or fall off. If this happens, a new adhesive backing may be needed to reattach it.
