



PCB Modifications

- 2 X's mark traces to be cut (top side)
- 15 □'s mark holes to be widened with .052" drill
- 3 O's mark new holes to be drilled with .052" drill

Connect a jumper on back side of PCB from J6-2 to O₁ hole. Connect to trace at O₁ on top of PCB.
 Connect a jumper on back side of PCB from O₃ hole to O₂ hole. O₃ end connects to trace on back of PCB.
 O₂ end connects to large trace on top of PCB.