

BAKUP-USA

BMW R1200GS WATER COOLED **ADVENTURE DRIVER**

1. Remove the pillion seat and turn it upside down.
2. Install the two (2) 8mm well nuts (provided) in the two (2) holes in the bottom of the pillion seat.
3. Place your new backrest over the front of the pillion seat.
4. Start the screws in the two (2) holes and tighten.
5. Reinstall the pillion seat on the bike.
6. Adjust to your liking.

GET ON YOUR BIKE AND RIDE !

****PERIODICALLY** CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**