BAKUP-USA INSTALLATION GUIDE

BMW R1200RT DRIVER'S BACKREST

- 1. Place your bike on the center stand.
- 2. Remove the driver and passenger seats.
- 3. Remove the two (2) height adjustment blocks.
- 4. Place your backrest so that the holes for the height adjustment block align with the mounting holes for your new backrest.
- 5. Re-install the height adjustment blocks using the hardware provided.
- 6. Re-install the driver and passenger seats.
- 7. Adjust to your liking.

NOTE – YOU MAY HAVE TO PUSH FORWARD ON THE BACKREST IN ORDER TO GET THE PASSENGER SEAT IN PLACE

GET ON YOUR BIKE & RIDE!

PERIODICALLY CHECK THE SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN