

BAKUP-USA

INSTALLATION GUIDE

BMW R1200RT WATER COOL DRIVER

1. Place your bike in a safe position.

2. Remove the driver seat.

3. Remove the two (2) thumb screws.

**Please note if your bike is 2016 or newer, you must remove the bushings located under the thumb screws.

4. Align the holes in the backrest with the holes for thumb screws.

5. Replace thumb screws (for seat in high position) see note below

6. Reinstall driver seat.

7. Adjust to your liking.

If using seat in low position, use hardware included

GET ON YOUR BIKE & RIDE !

****PERIODICALLY** CHECK THE SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**