

# BAKUP-USA

## INSTALLATION GUIDE

### BMW R1200RT WATER COOL PASS

1. Place your bike in a safe position.
2. Remove the driver and pillion seat.
3. Remove the 2 screws in front of the luggage rack and the rear of the pillion seat compartment.
4. Place the backrest over the front of the luggage rack so that the holes in the legs of the backrest align with the screw holes in the frame.
5. Install the 2 screws provided with 2 flat washers on each side.
6. Re-install the pillion and driver seats.
7. Adjust to your liking.

**GET ON YOUR BIKE & RIDE !**

**\*\*PERIODICALLY\*\* CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**