

BAKUP-USA

Installation Guide

BMW R1300GS Driver's Backrest

1. Place your bike in a safe location.
2. Remove the pillion seat.
3. Flip the pillion seat upside down and lift on the front side of the plastic undercarriage directly behind the driver's seat.
4. Line up your backrest with the 2 slots under the front of the pillion seat, then slide the backrest between the undercarriage and the seat until it snaps in place.
5. Reinstall the pillion seat.
6. Adjust to your liking.

GET ON YOUR BIKE AND RIDE !