BAKUP-USA

Installation Guide

KAWASAKI VULCAN 1500 NOMAD Driver's Backrest

- Remove the driver seat.
- Remove the pillion seat and place it upside down on a bench or a table.
- Remove the two nuts that hold the bracket and strap on the front of the pillion seat.
- Place your new backrest over the front of the pillion seat and over the two studs.
- Reinstall the bracket, strap and the two nuts.
- Reinstall the pillion seat and driver seat.
- Adjust to your liking.

GET ON YOUR BIKE AND RIDE!