

# **BAKUP-USA**

## **Installation Guide**

### **Suzuki Boulevard C50 & C50T Driver's Backrest FA & HO**

1. Remove the pillion seat.
2. Remove the two (2) screws that hold the forward bracket for the pillion seat.
3. Place your backrest under the bracket for the pillion seat so that all holes align.
4. Reinstall the screws.
5. Reinstall the pillion seat.
6. Adjust backrest to your liking.

***GET ON YOUR BIKE AND RIDE!***