BAKUP-USA

Installation Guide

Suzuki Boulevard M50 Driver's Backrest FA

- 1. Remove your pillion seat.
- 2. Remove the two screws that attach the rear bracket of the driver's seat.
- 3. Place your backrest so that the holes align with the holes where the screws were.
- 4. Install the two screws that are provided with your backrest.
- 5. Re-install the pillion seat.
- 6. Adjust to your liking.

GET ON YOUR BIKE AND RIDE!