

BAKUP-USA

Installation Guide

Yamaha FJR 1300 Driver's Backrest 07 & UP Model

- 1. Remove the pillion seat.**
- 2. Place your backrest over the front edge of the pillion seat and mark the (4) four holes.**
- 3. Drill the four holes using a 12.5 mm size bit.**
- 4. Insert the (4) four well nuts supplied with your backrest. Place your backrest over the pillion seat so that the mounting holes in the backrest align with the well nuts. Install the (4) four screws supplied with your backrest and tighten.**
- 5. Re-install the driver's seat and adjust to your liking.**

GET ON YOUR BIKE AND RIDE!