

Sweeps Installation Instructions

- Lift up the back end of the Renovating Leveler, TnT or Electrically Actuated Tracksetter so Skags are completely off the ground.
 - Support the Renovating Leveler, TnT or ETS securely.
- Loosen the 3/8" nut on front Skag retaining bolt. Remove the nut and washer and completely remove the bolt.
- Set the Sweep in place and insert the 3/8" bolt through front hole of the Sweep sandwiching the Sweep to the Skag.
- Install the washer and nut and snug up to keep the Skag in place.
- Loosen the front 3/8" nut on rear Skag retaining bolt. Remove the nut and washer completely remove the bolt.
- Rotate the Sweep into position.
- Install the bolt, washer and nut and snug up to keep the Skag in place.
- Tighten nuts on both retaining bolts.
- Repeat for the other Sweep.

Skags



Sweeps



Sweep Installed (Polyurethane)

Renovating Leveler/TnT



Electrically Actuated Track Setter

