

## APPLICATION

## INSTRUCTIONS

- \* Determine the number of Wild Animal Barriers needed to covers the panels also the inside and outside corners pieces.
- \*Some panels are different sizes so it is okay if the 5ft Wild Animal Barrier is longer or shorter. If longer no need to cut, you will cut at the end.
- \* Clean the top back of the Wild Animal Barrier thoroughly with acetone or fingernail polish remover to remove any dirt. Same with The side of the panels.
- \* Apply 3M VHB adhesive tape along the entire top back of the Wild Animal Barrier and inside corners and or outside corners.
- \* Pull the strip off the back of the barrier. Start at a corner and apply a corner piece. Continue with the 5-foot pieces the until the roof is covered.
- \* If necessary, cut a corner piece to fit at the end. If not it is okay to cut a 5ft piece.
- \* Use a roller or your hands to press firmly across the top of the Wild Animal Barrier to ensure the 3M adhesive tape adheres properly. Rolling or pressing with your hands helps the adhesive bond faster and more effectively to ensure the Wild Animal Barrier is securely attached to the solar panels to prevent movement that could attract wildlife.
- \*You may have different arrays. You may cut picese more or less.