

## SUPPLIES

To effectively prevent wildlife from infiltrating and damaging under the solar panels, it is crucial to have Wild Animal Barriers.

- \* Wild Animal Barriers
- \* 3M VHB adhesive tape
- \* Acetone or fingernail polish remover to wipe side of panels to remove dirt
- \* 3M VHB tape  $\frac{1}{8}$ - $\frac{1}{4}$  inch.
- \* Rags
- \* Roller
- \* Tin snips
- \* Metal marker
- \* Tape Measure
- \* Any type of knife
- \* 2 story ladder
- \* Safety Harness with tie off rope