

****Protecting Solar Panels from Wildlife Intrusion with 3M VHB Adhesive Tape****

To effectively prevent wildlife from infiltrating and damaging solar panels, it is crucial to apply 3M VHB adhesive tape strategically to the Wild Animal Barrier.

****Materials Required:****

- * Wild Animal Barriers
- * 3M VHB adhesive tape
- * Acetone or fingernail polish remover
- * Rag
- * Roller
- * 2 stoey ladder

*Safety Harnes with tie off rope

****Application Instructions:****

****1. Preparation:****

* Clean the top back of the Wild Animal Barrier thoroughly with acetone or fingernail polish remover to remove any dirt.

****2. 3M VHB Tape Placement:****

- * Apply 3M VHB adhesive tape along the entire top back of the Wild Animal Barrier.
- * Additionally, apply tape to any inside corners and outside corners.

****3. Calculating Barriers:****

* Determine the number of Wild Animal Barriers needed to cover the roof, including inside and outside corners.

****4. Installation:****

- * Start at a corner and apply a corner piece.
- * Continue with 5-foot pieces until the roof is covered.
- * If necessary, cut a corner piece to fit at the end.

****5. Rolling:****

* Use a roller to press firmly across the top of the Wild Animal Barrier to ensure the 3M adhesive tape adheres properly.

****Additional Notes:****

- * It is recommended to cut the corner pieces to fit since they do not have logos on them.
- * Rolling the tape helps the adhesive bond faster and more effectively.
- * Ensure the Wild Animal Barrier is securely attached to the solar panels to prevent movement that could attract wildlife.

