BOG Conversion Kit Instructions

Video Instructions: Installing BOG pod conversion kit

Tools Needed

1. Screwdriver
2. SAE Allen Wrench Set

Step 1

Start by removing the bolt on the bottom side of the BOG saddle using your Allen wrenches.

Step 2

Use a screwdriver to carefully remove the bushings from the bore of the BOG saddle.

Step 3

Take your RCK SOLID Conversion Kit and insert the round bushing into the bore.
Note: The bushing is designed to fit only one way.

Step 4

Gather the 3/8" bolt, two 1.5" washers, and the lock washer. Install the lock washer onto the bolt, followed by one 1.5" washer. Insert this assembly from the bottom. Place the second 1.5" washer on top, then thread your ball head onto the bolt.

Tighten until the lock washer is fully compressed (flat). Do not overtighten, as this may strip the threads in your ball head.

Step 5 (BOG Adapter)

If you wish to continue using your BOG saddle clamp, remove the four bolts on the bottom of the saddle clamp. Install the provided adapter and reuse the original bolts to secure it.

Do not overtighten these bolts, as this may damage the adapter. Tighten until snug.