



Sacrete or similar products must be mixed as per installation instructions with water in a wheel barrow or mixer. Dry placement in hole will be rejected.

TYPICAL POLE BUILDING