



# RIMLOX

*To Serve and Protect...YOUR WHEELS* .com



## **RIMLOX REGISTRATION AND INSTALLATION INSTRUCTIONS**

The Rimlox wheel locks **MUST** be registered within 24hrs **AFTER** wheel locks have been installed. Failure to register within 24hrs after installation will result in a **\$350 late registration fee**. (Must be paid prior to Rimlox accepting your registration.)

### **ONLINE REGISTRATION**

**The Rimlox wheel locks Must register within 24hrs after installation**

1. Visit: <https://rimlox.com/registration>
2. Customer must ship (install) key back to Rimlox to have sealed (Unless self installed. **MUST** still register)
3. **Must enter tracking # prior to filling out and submitting registration.**
4. Fill in all required information and submit

**NOTE:** All registration forms are automatically time stamped to verify submission time and date registration was submitted.

### **INSTALLATION**

1. Remove wheel locks and installation key (red label) from baggie. (Do not use 2-part key for initial install)
2. Remove one wheel lock from each wheel
3. Match wheel lock(s) pattern with installation key
4. Hand-tighten wheel lock onto wheel stud(s)
5. Repeat steps 3-4 for additional locks
6. Torque each wheel lock to vehicle OEM torque specs (no exceptions)
7. Give installation key back to customer
8. Dealer/installer must provide customer with basic company information:

Company name, installer first and last name, email and phone number

**NOTE:** No need to record or keep records of installation, customer will provide and submit all installation information to Rimlox

### **DUMMY CAPS**

**WARNING: Do not torque or use air gun on dummy caps** (whereas they will strip)

1. Remove dummy caps from baggie
2. Hand-tighten/snug dummy cap(s) on top of the Rimlox wheel locks
3. Repeat for additional dummy caps

**NOTE: \$80 per stripped dummy cap replacement (plus shipping)**

**For any additional questions or concerns, please contact us  
Rimlox (813) 586-2100**