



Installation Manual










Classic (SC-82)





Exploded Diagram



Parts List


1	 x4	2	 x6	3	 x2	4	 ST4x30 x6	5	 x2	6	 x2
7	 x1	8	 x1	9	 x2						

Tools Required




Dimension	Size A	Door B	Door C	Opening space D
48" x 76"	48"	24 1/2"	24 1/2"	21 1/2"
54" x 76"	54"	27 1/2"	27 1/2"	24 1/2"
60" x 76"	60"	30 1/2"	30 1/2"	27 1/2"
60" x 58"	60"	30 1/2"	30 1/2"	27 1/2"
66" x 76"	66"	33 1/2"	33 1/2"	30 1/2"


Step 1




Step 2




X1




X2




X6




X6




X6





X6






X6



Step 3




Step 4



X4



X2



Step 5

DO NOT USE THE ENCLOSURE FOR
24 HOURS AFTER SEALING

