




The #187 orientates the fish head first and belly to the right, in four channels, side-by-side, and automatically feeds the fish pockets of Headers and Nobbers.

Feed wheels synchronized electrically with the heading machine automatically load the Header pockets with singulated, oriented and timed fish.

Suitable for:

- Herring
- Horse Mackerel
- Mackerel
- Sardine
- Pacific Saury
- Crunida (thread herring)
- Other similar fish




ELECTRICAL:

- Most hardware components can be purchased worldwide from stocking distributors
- System is "Plug and Play", and can be set up and operated in minutes by untrained personnel
- Electrical components rated to IP68+

MECHANICAL:

- Variable speed drives
- Components are standard stocked items worldwide
- Heavy stainless frame
- Stainless bearings



SPECIFICATIONS MAY CHANGE, CONTACT RYCO FOR SPECIFIC APPLICATIONS

OVERLEAF: D4139-A1

Address: 6810 220th St. SW
Mountlake Terrace, WA 98043
USA

Phone #: 425-744-0444
Fax #: 425-673-2666

Web: rycous.com
E-mail: sales@rycous.com