

### Limited Warranty

J & J Global, LLC (Seller) warrants to the original Buyer only, that each product will be free from defects in material and workmanship for a period of one (1) year from date of purchase. SELLER'S SOLE OBLIGATION AND BUYER'S EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE THE REPAIR OR REPLACEMENT OF PARTS, WITHOUT CHARGE, WHICH ARE DEFECTIVE IN MATERIAL OR WORKMANSHIP. ANY PARTS AS DETERMINED BY THE SELLER WHICH HAVE BEEN MISUSED; ABUSED OR DAMAGED EITHER DIRECTLY OR INDIRECTLY FROM REPAIRS OR ALTERATIONS ATTEMPTED BY UNAUTHORIZED PERSON; IMPROPER MAINTENANCE, NEGLIGENCE OR ACCIDENT ARE NOT COVERED BY THIS LIMITED WARRANTY. This warranty does not apply to damage, heat-induced coloration changes, scratching or alteration due to normal use or weathering. To make a claim under this Limited Warranty, email [contact@ezreplacement.com](mailto:contact@ezreplacement.com) or visit [www.ezreplacement.com](http://www.ezreplacement.com) for warranty questions and claims.

#### Additional Limitations

THIS LIMITED WARRANTY DOES NOT APPLY TO ACCESSORY OR CONSUMABLE ITEMS RELATED TO THIS PRODUCT. ALL IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO ONE (1) YEAR FROM DATE OF PURCHASE. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS, ARISING FROM THE SALE OR USE OF THIS PRODUCT.

If any provision of this Limited Warranty is for any reason held to be invalid or unenforceable, such provision shall not affect any other provision herein, this Limited Warranty shall be construed as if such invalid and/or unenforceable provision had never been contained herein.

This warranty gives you special legal rights, and you may also have other rights which vary from state to state.

This warranty contains the entire agreement between Seller and Buyer and supercedes any and all prior agreements, arrangements, or understandings between the parties relating to product warranty.

Due to ongoing product development the actual product or products may vary from the illustrations or photos shown within this manual.


For Manuals, Replacement Parts or Customer Service visit:  
[www.ezreplacement.com](http://www.ezreplacement.com)

This product is intended for residential, non-commercial use.

#### ⚠ WARNING

This product can expose you to lead, a chemical known to the state of California to cause cancer, birth defects and/or other reproductive harm. For more information go to [www.p65warnings.ca.gov/product](http://www.p65warnings.ca.gov/product)

**MADE IN CHINA**  
©2019 J & J Global, LLC  
Distributed By:  
J & J Global, LLC  
Carrollton, TX 75006



- User Friendly Interface
- Download Product Manuals
- Email your questions or concerns
- File Warranty Claim
- Follow-up within 24 Hrs
- Parts Ship within 48 Hrs.



Parts distribution made from our Carrollton, TX warehouse facility

## ATTENTION!

Please do not return this product to the retailer.  
If you are missing or have damaged parts please email  
[contact@ezreplacement.com](mailto:contact@ezreplacement.com) Or Call 877-477-2264



# Rose Garden Bench

SKU: 203052, 203053



Read the instructions and precautions before use of this product

Please keep this instruction manual for future reference


For warranty information, please refer to the back page of this instruction manual.

# 4

**CAUTION:** Do not over tighten fasteners.

1. (See Illustration) Align the holes in the bench back (I) and bench seat (J) to the holes in the bench arms (K) and push the plain head screws (E) through each hole. Secure the screws with small washer (F), spring washer (B) and small hex nut (G).


Tighten all fasteners and place the plastic hex nut caps (H) over the small hex nuts (G) that are on the back of the bench back (I).











# 3

**CAUTION:** Do not over tighten fasteners.



1. (See Illustration) Align the holes in the bench back (I) to the holes in the bench seat (J) and push the plain head screws (E) through each hole. Secure the screws with small washer (F), spring washer (B) and small hex nut (G).








## Hardware Contents

<b>A</b> Set Screw with Hex Head <b>x8</b> 	<b>B</b> Spring Washer <b>x9</b> 	<b>C</b> Large Washer <b>x8</b> 	<b>D</b> Large Hex Nut <b>x8</b> 
<b>E</b> Plain Head Screw <b>x9</b> 	<b>F</b> Small Washer <b>x9</b> 	<b>G</b> Small Hex Nut <b>x9</b> 	<b>H</b> Plastic Hex Cap <b>x2</b> 

## Tools Needed


Hex Key 	Phillip's Screw Driver  <b>Not Included</b>
--	--

## Package Contents

<b>I</b> Bench Back <b>x1</b> 	<b>J</b> Bench Seat <b>x1</b> 	<b>K</b> Bench Arms <b>x2</b> Left  Right 	<b>L</b> Bench Leg <b>x4</b> 
---	---	--	--

# 1

1. (See Illustration) Screw set screw with hex head (A) into appropriate holes on the underside of bench seat.



# 2

**CAUTION:** Do not over tighten fasteners.

1. (See Illustration) Align each leg to the set screw with hex head (A) and slide the set screw with hex head through the holes in the leg.

2. (See Illustration) Secure each leg with large washer (C) and large hex nut (D).

