


-- PRECICO --

-- TRANSMISSION -- 04



PRECICO TRANSMISSION

Page 1 of 3

ALSPORT PART NO. 617-105

<u>ITEM NO. & PART NO.</u>	<u>DESCRIPTION</u>
1 40430-016	Air Vent
2 40430-000	Locker Ball
3 40416-001	Locker Ball Spring
4 41212-023	Hex Nut
5 41213-003	Lock Washer
6 40420-000	Transmission Casing Gasket
7 40402-007	Transmission Casing LH
8 41218-000	Ball Bearing
9 40402-003	Input Shaft
10 40419-007	Transfer Gear 21T
11 40418-000	Ball Bearing
12 40402-008	Shifter Fork
13 40404-002	Fork Lever
14 41213-003	Lock Washer
15 41211-005	Hex Cap Screw
16 41213-006	Flat Washer
17 41212-015	Lock Nut
18 40403-004	Shifter Lever
19 40404-003	Shifter Housing
20	Hex Head Bolt
21 40402-019	Square Key
22 41214-202	Snap Ring

10-74

<u>ITEM NO. & PART NO.</u>	<u>DESCRIPTION</u>
23 41220-002	Shifter Housing Gasket
24 41220-001	"0" Ring
25 40402-002	Transmission Shaft
26 40419-006	Gear 30T
27 40402-005	Spacer
28 40419-004	Gear 21T
29 41214-001	Dowel Pin
30 41220-000	Oil Seal
31 40404-004	Oil Gauge
32 40402-023	Spacer
33 40430-015	Square Driver Plug
34 40419-005	Gear 23T
35 40402-004	Spacer
36 40419-015	Gear 45T
37 40211-007	Hex Head Bolt
38	NOT USED
39 41218-001	Ball Bearing
40 40402-001	Differential Body
41 41212-005	Lock Nut
42 41217-003	Flanged Bearing
43 40419-014	Bevel Gear 18T
44 40419-011	Pinion 12T
45 40402-026	Thrust Bearing
46 40402-011	Pinion Axle

10-74

<u>ITEM NO. & PART NO.</u>	<u>DESCRIPTION</u>
47 40402-010	Pinion Pin
48 40419-017	Gear 87T
49 40402-006	Transmission Casing RH
50 41211-004	Hex Head Bolt
51 41215-000	Plug