

Parade and Field Stock Rules

Antique Steel (1938 & Older) Rules

- Tractors must be field ready with a stock appearance and with standard sized tires, front and back for that model. Extra small or large tires, cutting or grooving of tires, duals or track units will not be allowed. Steel wheel class tractors will be allowed to run extensions.
- **Tractors must have a stock engine!! No stroking of the engine.** Factory available overbore for that model is acceptable. Tractors will be allowed a 5% over stock RPM for that model. This class is intended for those who use their tractors for field and parade or show duties, not dedicated pulling tractors. A points replacement to electronic ignition inside the factory distributor, alternators and straight pipes will be allowed.
- Tractors must utilize a factory drawbar. Tractors will pull from the swinging drawbar under the belly if factory equipped, not the horseshoe. An example of this would be a Farmall H or M. The drawbar has to be 24" back from the centerline of the rear axle and no higher than 16" measured off the hook point on the clevis. Drawbars must be stationary in all directions and not be able to be changed from the seated drivers' position. All fast hitches, tractors with 3 points will have to have the hitch locked out.
- All factory weights, and/or liquid ballast will be permitted if they came out with that model of tractor. No aftermarket or home built weight brackets will be permitted on the tractor. No extra ballast under the seat, in the tool tray or in the frame on this class.
- All tractors will run a 12" taddle-tale chain, when the chain is off the ground the pull will be terminated and the distance taken from that spot. This includes tractors equipped with wheelie bars in the stock class, IE someone pulling under the age of 16.

Parade and Field Stock (1969 and Older)

0-2500lbs (2500lb Class)---Uses the small sled

2501lbs-3000lbs (3000lb Class) uses the small sled

3001lbs-3500lbs (3500lb Class) uses the big sled

3501lbs-4000lbs (4000lb Class) uses the big sled

4001lbs-4500lbs (4500lb Class) uses the big sled

4501lbs-5000lbs (5000lb Class) uses the big sled

5001lbs-5500lbs (5500lb Class) uses the big sled

5501lbs-6000lbs (6000lb Class) uses the big sled

6001lbs-6500lbs (6500lb Class) uses the big sled

6501lbs-7000lbs (7000lb Class) uses the big sled

7001lbs-7500lbs (7500lb Class) uses the big sled

7501lbs-8000lbs (8000lb Class) uses the big sled

7501lbs-8500lbs (8500lb Class) uses the big sled

These classes will get a 1% weight allowance