## **Speedometer Mechanical to Electrical Adapter**

It is designed to take 2 different cable sizes. You need to check the size of the square end of the drive cable from your bus, either 2.55mm or 2.70mm, to determine which configuration you need. The smaller cable will fit the larger adapter, but it will not drive correctly due to cable slip.



Picture 1:- The 2 cable size options.



Picture 2:- If your drive cable is 2.70mm, use pin & white extension adapter



Picture 3:- If your drive cable is 2.55mm, remove pin & white extension adapter

IMPORTANT

Once you have connected the original speedometer cable to the sender, ensure it is securely tied down to prevent bounce. We recommend at least 2 points of contact.