


Tel: (852) 8109 8368 Fax: (852) 3007 4857 Email: sales@ysftool.com

Supply, Repair, Rental, Scanning Service and Calibrate of Surveying Instruments and Accessories



### MAIN WORKFLOW FOR MSP RAPID™ ADMS SUITE










# MSP RAPID™ CONVERGENCE

## **Section Layout**


Section 1: SEC001



Prism are installed in the Tunnel Sections
Minimum of 5 prisms should be installed per Section

# **Section Layout**


Section 1: SEC001



The installed prisms are then connected by lines and creating 2 triangles RAPID Convergence calculates the measurement between the connecting lines of the prisms

**MONITORING SITE** 

### **MONITORING SITE**



Total Station will take measurement of the prisms from the lower left to right or from Prism 1 – 5 of the section

# SEC003

Monitoring Station

Convergence will take measurement for all the sections