

Customer Care Requirements

Getting the most out of your Gorilla Pump Station involves some essential routine maintenance checks.


Please contact us if you have any questions

Sewer Pump Stations

- Check for oils and fats building up around the pump float. Remove them if seen.
- Ensure no wet wipes are introduced into the pump station or it's outlets (your local Council does not like them either)
- Check that the pump float is not in contact with the chamber walls

Storm Water Pump Stations

- Check for debris in pit box
- Periodically wash the inner walls of the chamber with high pressure hose and activate pump. This will flush out the chamber and introduce fresh water.
- Check that the pump float is not in contact with the chamber walls.



GORILLA PUMP STATIONS

Further and Faster



Eco Water Solutions

PO Box 18, Foxtton Beach

021 745 335