














JULIET TUFTED CHAIR

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.


PARTS LIST			
ITEM	DESCRIPTION	SKETCH	QUANTITY
A	SOFA LEG		4
BL	LEFT ARM		1
BR	RIGHT ARM		1
C	FRONT RAIL		1
D	BACK RAIL		1
E	SEAT FRAME		1
F	BACKREST		1
G	SEAT CUSHION		1
1	PLASTIC WASHER		4
2	ALLEN KEY		1
3	WASHER		4
4	BOLT		4




ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until assembly is complete.


STEP 1




STEP 2



STEP 3




STEP 4




Open & take out the legs


STEP 5




STEP 6



STEP 7



STEP 8



CLEANING INSTRUCTIONS: Clean with soft cloth

ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll-free, customer service number and have this assembly manual open to the parts list ready to provide the model name, number and part name or number.



Customer Service

1-877-864-5752
 8:30 AM PST - 4:00 PM PST (Monday-Friday)
 Website: www.dwellhom.com
 Missing Parts: parts@dwellhom.com
 Warranty Information: www.dwellhom.com/warranty

WARNING: This product may contain small components, please ensure they are kept away from small children.