

# Agile Boost Electric Desk

Form and function at a great price point. Increase your health with an electric sit/stand desk at home or fit-out your office to accommodate a range of users creating a multi-functional and healthier work environment.



## FEATURES

- Two column electric frame with square style leg and flat foot in your choice of powdercoat finish.
- Commercial-grade 25mm worktop finished in melamine with 2mm PVC edge.
- Single motor with low noise level - no co-worker disturbance or irritation.
- Digital handset with height readout and 4 point memory.
- Add additional functionality by upgrading to a bluetooth adaptor (control your desk via iOS or Android device).
- Adjustable height range 720 - 1200mm (\*includes worktop).
- Agile Boost frame suits top sizes 1200 - 1800mm.
- Optional cable trays and management are available.

15  
YEAR  
WARRANTY  
\*\*\*\*\*

↑↓  
**HEIGHT  
ADJUSTABLE**

**E1  
BOARD  
CERTIFIED**

**ISO  
14001  
EMS**



## Electric 2 Column

- 1800w x 800d
- 1500w x 800d
- 1200w x 700d
- Adjustable height 720 - 1200mm\*
- Up and down speed 22mm/sec
- 80kg static load weight
- Power type: 90 - 230V AC
- Leg size: 60 x 60mm
- Feet length: 680mm



## Frame



White P/C    Silver P/C    Black P/C

## Melamine / PVC Edge



White    Silver    Nordic Maple    Atlantic Oak    Black

**K KNIGHT**

knightgroup.co.nz

# Agile Boost Upgrade

## Agile Boost (Standard)

Adjust up & down and save favourite heights with a 4 point memory digital handset.



## Agile Boost (Upgrade)

Bluetooth to control via iOS or android device with SitStand Desk App.

App Icon



Bluetooth

**Sit Stand Desk App** - Personalise your desk through your iOS or android device with an easy to use interface.

- Set minimum and maximum heights.
- Set reminders for standing & sitting or set on auto and desk will operate automatically when it is time to change position.
- Data analysis and statistical functions (standing/ sitting time and calories burned).
- Set position favourites - 3 height memory settings.
- Error code prompt and fix solution.
- Desk name and language settings.
- Turn off - Lock mode for hand controller.

