

## TIPS AND TRICKS FOCUSED ON SETTINGS AND SAFARI

February 18, 2022

1. ENLARGE PRINT: Settings>Accessibility>Display & Text Size>Larger Text>Move dot on continuum to select desired print size.

2. BATTERY Usage: Settings>Battery>Adjust Low Power Mode or Check battery usage

3. CLEAR WEBSITE DATA (including cookies): Settings>Safari>Clear History and Website Data (Print changes from blue to grey to indicate data was cleared.)

### 4. SCREENSHOT:

iPads: Press Home Screen button and On/Off switch at the same time.  
Screenshot>Done>Save to Photos or Files (or Delete).

Newer iPhones: Hold and press On/Off button and Raise Volume button at the same time. Screenshot saved in Photos.

### 5. SAFARI

1. Remove Sidebar - Tap the book icon at the top left to return to fullscreen
2. Bookmarks > go to site you want > Share icon (square with arrow) and select  
Reading List  
Favorites  
Menu

### 6. TROUBLESHOOTING

a. Turn your device Off > turn device On

b. Force Quit

Older versions > Press Home button and On/Off button at same time  
until screen goes black > wait for Apple icon to appear

Newer devices > Press and hold Volume Up > release  
> Press and hold Volume Down > release  
> Hold the ON/Off switch until the Apple logo appears > release

7. WEBSITE SUPPORT > [vptechclub.org](http://vptechclub.org) > iPad > Resources > Listing of class presentations