

# Instructions for Grill Assembly






1.- Find a fairly level surface to assemble your grill.



2.- Take off wing nuts (a) and untie linchpins from steel cable(b),.



3.- Find plate #1 and #2. Insert plate #2 on left slots of plate #1 with numbers facing inside the assembly, insert two linchpins to secure plates in place.



4.- Find plate #3 and insert it in right slots of plate #1 with numbers facing inside the assembly, insert two linchpins to secure plates in place.






5.- Find plate #4. Position it exactly as shown on the top right picture, plate #2 and #3 touching plate #4. Pay attention to hooks(c) on plate #4.



6.- Slide plate #4 and insert in bottom slots on plate # 1,#2,and#3, insert two linchpins to secure plates in place.






7.- Make sure there are six linchpins on the back of the grill as shown on the top right picture.



8.- Flip the whole assembly facing up as shown on the bottom right picture.



9.- Find plate #5 and insert it in the remaining slots on plates #1,#2, and #3 as shown on the top right picture.



10.-Make sure that the front of plate #4 and #5 are touching the bottom side of slots on plates #2 and #3 to receive plate #6.





11.- Place plate #6 on the remaining side. Insert all the remaining linchpins (8 on the front and 2 on the back).



12.- Stand the assembly upright and place the grill. Make sure all 16 linchpins are installed before you fire the grill.  
The grill is ready to use, enjoy.



# Care and Maintenance Guide

- Make sure you install all 16 linchpins before you fire the grill, they are not only to keep plates together but also to prevent steel plates from warping.
- Never pour water onto the grill to cool it down, it may speed up rusting and may warp the plates. If you want to speed up cooling we suggest to shovel the embers out of the grill and into a bucket of water.
- To extend the life of your grill keep away from inclement weather as much as possible and paint as needed.