

Model	Method	Fastener	Special Instructions	Recommended Heads
274	Curved Shaft Instructions	5/16 x 18 RHM		3600, 4700, 5600, 5620, 8010
275	Curved Shaft Instructions	5/16 x 18 RHM		3600, 4700, 5600, 5620, 8010
284	Straight Shaft Instructions	10mm x 1.25 LHF		Any of our heads will fit
285	Straight Shaft Instructions	10mm x 1.25 LHF		Any of our heads will fit
520	Straight Shaft Instructions	3/8 x 24 LHF		Any of our heads will fit
700R	Curved Shaft Instructions	5/16 x 18 RHM		3600, 4700, 5600, 5620, 8010
704R	<i>Doesn't Fit</i>	<i>Doesn't Fit</i>	<i>No threaded shaft. Bottom of the spool is held in place by tabs. Spool is held in place by a retainer washer.</i>	N/A
705R	<i>Doesn't Fit</i>	<i>Doesn't Fit</i>	<i>No threaded shaft. Bottom of the spool is held in place by tabs. Spool is held in place by a retainer washer.</i>	N/A
720R	Curved Shaft Instructions			3600, 4700, 5600, 5620, 8010
725R	Curved Shaft Instructions	8mm x 1.25 RHF		3600, 4700, 5600, 5620, 8010
740R	Straight Shaft Instructions	10mm x 1.25 LHF	Curved shaft that follows the straight shaft instructions.	3600, 4700, 5600, 5620, 8010
750R	Straight Shaft Instructions	10mm x 1.25 LHF	Curved shaft that follows the straight shaft instructions.	3600, 4700, 5600, 5620, 8011
750R	Curved Shaft Instructions	Bolt in the kit	Straight shaft that follows the curved shaft instructions	3600, 4700, 5600, 5620, 8011
760R	Curved Shaft Instructions	5/16 x 18 RHM	Straight shaft that follows the curved shaft instructions	3600, 4700, 5600, 5620, 8010

Model	Method	Fastener	Special Instructions	Recommended Heads
764R	Curved Shaft Instructions			3600, 4700, 5600, 5620, 8010
765R	Curved Shaft Instructions	5/16 x 18 RHM	Straight Shaft that follows the curved shaft instructions	3600, 4700, 5600, 5620, 8010
766R	Curved Shaft Instructions	5/16 x 18 RHM	Straight Shaft that follows the curved shaft instructions	3600, 4700, 5600, 5620, 8010
767R	Curved Shaft Instructions		Straight shaft that follows the curved shaft instructions	3600, 4700, 5600, 5620, 8010
768R	Straight Shaft Instructions			Any of our heads will fit
770R	Straight Shaft Instructions			Any of our heads will fit
775R	Curved Shaft Instructions	10mm x 1.25 LHF / 8mm x 1.25 RHF	Straight shaft that follows the curved shaft instructions	Any of our heads will fit
780R	Straight Shaft Instructions	10mm x 1.25 LHF	Remove shaft extender	Any of our heads will fit
790R	Straight Shaft Instructions	10mm x 1.25 LHF	Remove shaft extender	Any of our heads will fit
790R (version 2)	Curved Shaft Instructions	3/8 x 16 LHM	Housing is held in place by a pressure washer and can't be removed. Follow the curved shaft instructions.	3600, 4700, 5600, 5620, 8010
825R	Curved Shaft Instructions	3/8 x 16 LHM		3600, 4700, 5600, 5620, 8010
840R	Straight Shaft Instructions	10mm x 1.25 LHF		Any of our heads will fit
865R	Straight Shaft Instructions	10mm x 1.25 LHF	Remove shaft extender	Any of our heads will fit
875R	Curved Shaft Instructions	8mm x 1.25 RHF	Straight shaft that follows the curved shaft instructions	3600, 4700, 5600, 5620, 8010
885R	Straight Shaft Instructions	10mm x 1.25 LHF		Any of our heads will fit

Model	Method	Fastener	Special Instructions	Recommended Heads
890R	Straight Shaft Instructions	10mm x 1.25 LHF	Remove shaft extender	Any of our heads will fit
960R	Straight Shaft Instructions	5/16 x 18 RHF		Any of our heads will fit
975R	Curved Shaft Instructions	8mm X 1.25 RHF	Straight shaft that follows the curved shaft instructions	3600, 4700, 5600, 5620, 8010
990R	Straight Shaft Instructions	10mm x 1.25 LHF		Any of our heads will fit
1079R	Straight Shaft Instructions		Remove shaft extender	Any of our heads will fit
2079R	Straight Shaft Instructions			3600, 4700, 5600, 5620, 8010
BC 30	Straight Shaft Instructions			Any of our heads will fit
CS 30 with tabs holding the bottom of the housing in place	R5607 adapter instructions		Request adapter R5607	Use only 3600, 4700, 5600, 5620, 8010. No Bump & Feed heads
CS 30 with threaded Bump Knob	Curved Shaft Instructions			3600, 4700, 5600, 5620, 8010
CS26 with tabs holding the bottom of the housing in place	R5607 adapter instructions		Request adapter R5607	Use only 3600, 4700, 5600, 5620, 8010. No Bump & Feed heads
CS26 with threaded Bump Knob	Curved Shaft Instructions			3600, 4700, 5600, 5620, 8010
CS430	R5607 adapter instructions		Request adapter R5607	Use only 3600, 4700, 5600, 5620, 8010. No Bump & Feed heads

Model	Method	Fastener	Special Instructions	Recommended Heads
ES30 / RY29550	Straight Shaft Instructions with R5280		Splines. Request an R5280 adapter	Any of our heads will fit
IDC 540	Straight Shaft Instructions	10mm x 1.25 LHF		3600, 4700, 5600, 5620, 8010
IDC 580		10mm x 1.25 LHF		Any of our heads will fit
RD1605	Straight Shaft Instructions			Any of our heads will fit
RD180K	Straight Shaft Instructions	8mm x 1.25 LHM		Any of our heads will fit
RD2414	Straight Shaft Instructions			Any of our heads will fit
RD280		10mm x 1.50 LHF		Any of our heads will fit
RD330	Straight Shaft Instructions	12mm x 1.75 LHF	Nut not included in the kit. Request one	Any of our heads will fit
RD3318	Straight Shaft Instructions	8mm x 1.25 LHM	Rare occasion were a straight shaft takes a bolt. Bolt not in the kit. Request one (R5255)	3600, 4700, 5600, 5620, 8010
RD430	Straight Shaft Instructions	12mm x 1.75 LHF	Nut not included in the kit. Request one	Any of our heads will fit
RD520	Straight Shaft Instructions	12mm x 1.75 LHF	Nut not included in the kit. Request one	Any of our heads will fit
RD5224	Straight Shaft Instructions			Any of our heads will fit
RSB2801	Straight Shaft Instructions	10mm x 1.25 LHF		Any of our heads will fit
RSH1100	Straight Shaft Instructions			Any of our heads will fit
RY251HP	Curved Shaft Instructions	8mm x 1.25 LHM	Bolt not included in the kit. Request one	3600, 4700, 5600, 5620, 8010

Model	Method	Fastener	Special Instructions	Recommended Heads
RY253SS	Curved Shaft Instructions	Bolt in the kit	Straight shaft that follows the curved shaft instructions	3600, 4700, 5600, 5620, 8010
RY26000 (EX26)		Powerhead part of an attachment capable set	Installation instructions depends on attachment used	Depends on attachment used
RY26250	Curved Shaft Instructions	Bolt from the kit	Straight shaft that follows the curved shaft instructions. Request an R5280 spacer if there's still a gap after installation.	3600, 4700, 5600, 5620, 8010
RY28045	Straight Shaft Instructions		Remove shaft extender. Spool Shaft is on a reverse thread.	Any of our heads will fit
RY28121	Curved Shaft Instructions	Bolt in the kit	Request an R5280 spacer if there's a gap after installation	3600, 4700, 5600, 5620, 8010
RY30544	Straight Shaft Instructions		Remove shaft extender	Any of our heads will fit
RY30550	R5607 adapter instructions		Request adapter R5607	3600, 4700, 4600, 5600, 5620, 6700, 8010
RY30951	Powerhead part of an attachment capable set		Engine part of an Expand-it. Usually comes with Attachment RY30550	Depends on attachment used
RY34420	R5607 adapter instructions		Request adapter R5607	3600, 4700, 4600, 5600, 5620, 6700, 8010
RY34425	Curved Shaft Instructions			3600, 4700, 4600, 5600, 5620, 6700, 8010
RY34440 (S430)	Curved Shaft Instructions		Follow the curved shaft instructions. Request an R5280 spacer if there's still a gap after installation.	3600, 4700, 4600, 5600, 5620, 6700, 8010

Model	Method	Fastener	Special Instructions	Recommended Heads
RY34446	Straight Shaft Instructions	8mm x 1.25 LHF	Remove shaft extender	Any of our heads will fit
RYSST44	Curved Shaft Instructions	Bolt in the Kit	Follow the curved shaft instructions. Request an R5280 spacer if there's still a gap after installation.	3600, 4700, 4600, 5600, 5620, 6700, 8010
SS 30	Straight Shaft Instructions		Remove shaft extender	Any of our heads will fit
SS26	Straight Shaft Instructions	10mm x 1.25 LHF		Any of our heads will fit