



600 3rd Ave, Laval, QC, H7R 4J4
 Tel: (514)631-2173
 Fax:(450)627-2199
 email: quotes@aeroneuf.com



BOEING 737 CAPABILITY LIST

Part Number	Manufacturer	Description	Aircraft
10031-0000-01	Simmonds Precision	Engine Oil Quantity Indicator	737
10033-0000-02	Simmonds Precision	Hydraulic Oil Quantity Indicator	737
10034-0000-02	Simmonds Precision	Hydraulic Oil Quantity Indicator	737
10037-1000-0151	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0152	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0153	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0154	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0155	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0156	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0157	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0158	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0159	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0160	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0161	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0162	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0163	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0164	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0165	Simmonds Precision	Fuel Quantity Indicator	737
10037-1000-0166	Simmonds Precision	Fuel Quantity Indicator	737
10051-0000-01	Simmonds Precision	Engine Oil Quantity Indicator	737
10054-0000-01	Simmonds Precision	Engine Oil Quantity Indicator	737
10066-0000-01	Simmonds Precision	Fuel Quantity Indicator	737
114.029	Rogerson/Kratos	Position Indicator	737
124.835	Rogerson/Kratos	Frequency Meter	737
13CT-0213-A	Astro Instruments	Transformer, Control Surface Position	737
13TX-0115-A	Astro Instruments	Transmitter, Control Surface Position	737
146895-01-01	Smiths/Lear Siegler	Total Air Temperature Indicator	737
147LC10	Horizon Aerospace	Gen. Drive Oil Temperature Indicator	737
149LA6	Horizon Aerospace	DC Ammeter Indicator	737
149LA7	Horizon Aerospace	AC Ammeter Indicator	737
149LF10	Horizon Aerospace	Frequency Indicator	737
149LV11	Horizon Aerospace	AC Voltmeter	737
149LV8	Horizon Aerospace	DC Voltmeter Indicator	737
152BL702	Horizon Aerospace	Temperature Indicator	737
152BL702A	Horizon Aerospace	Temperature Indicator	737
152BL706	Horizon Aerospace	Temperature Indicator	737
152BL801	Horizon Aerospace	Temperature Indicator	737
152BL801A	Horizon Aerospace	Temperature Indicator	737
152BL801C	Horizon Aerospace	Temperature Indicator	737
152BL801D	Horizon Aerospace	Temperature Indicator	737
152BL801E	Horizon Aerospace	Temperature Indicator	737

152BL802A	Horizon Aerospace	Temperature Indicator	737
152BL802D	Horizon Aerospace	Temperature Indicator	737
152BL803	Horizon Aerospace	Temperature Indicator	737
152BL803A	Horizon Aerospace	Temperature Indicator	737
152LMA18	Horizon Aerospace	Temperature Indicator	737
152LMA22	Horizon Aerospace	Temperature Indicator	737
152LMA23	Horizon Aerospace	Temperature Indicator	737
154LUA104	Horizon Aerospace	Valve Position Indicator	737
162BL502	Horizon Aerospace	Temperature Indicator	737
162BL505	Horizon Aerospace	Temperature Indicator	737
162BL701	Horizon Aerospace	Temperature Indicator	737
162BL704C	Horizon Aerospace	Temperature Indicator	737
162BL704L	Horizon Aerospace	Temperature Indicator	737
162BL801	Horizon Aerospace	Temperature Indicator	737
162BL802	Horizon Aerospace	Temperature Indicator	737
162BL802A	Horizon Aerospace	Temperature Indicator	737
162BL803	Horizon Aerospace	Temperature Indicator	737
162BL803A	Horizon Aerospace	Temperature Indicator	737
162BL902	Horizon Aerospace	Temperature Indicator	737
162BL903	Horizon Aerospace	Temperature Indicator	737
162BL906	Horizon Aerospace	Temperature Indicator	737
163BL511	Horizon Aerospace	Temperature Indicator	737
163CV59	Horizon Aerospace	Water & Waste Quantity Indicator	737
163CV64	Horizon Aerospace	Water & Waste Quantity Indicator	737
163LCP80	Horizon Aerospace	Brake Accumulator Pressure Indicator	737
1680-4U-A2	Courter	Rate of Climb Indicator	737
1783867-11	Honeywell/Sperry	Servo Amplifier	737
1783867-3	Honeywell/Sperry	Servo Amplifier	737
1784460-655	Honeywell/Sperry	Gyrosyn Compass Indicator	737
1784460-657	Honeywell/Sperry	Gyrosyn Compass Indicator	737
18-1299	Courter	Flap Position Ind	737
18-1299-6	Courter	Flap Position Indicator	737
18-1299-6-2	Courter	Flap Position Indicator	737
182936	Ametek/Weston	Oxygen Pressure Indicator	737
182972	Ametek/Weston	Oxygen Pressure Indicator	737
185.076	Rogerson/Kratos	AC Ammeter Indicator	737
1925179-5	Bendix	Radio Magnetic Indicator	737
1925179-6	Bendix	Radio Magnetic Indicator	737
1925179-7	Bendix	Radio Magnetic Indicator	737
1925179-9	Bendix	Radio Magnetic Indicator	737
1G11-3	Parker Aerospace	Suction Gauge Indicator	737
1G386	C.C.S.	Pressure Switch	737
20041-0000-03	Simmonds Precision	Liquid Qty Engine Oil Transmitter	737
2061-14-1	Smiths Industries	Flap Position Indicator	737
2581942-901	Honeywell/Sperry	Roll Rack Self-Test Panel	737
2581942-903	Honeywell/Sperry	Roll Rack Self-Test Panel	737
2587317-653	Honeywell/Sperry	Gyrosyn Compass Indicator	737
2587317-655	Honeywell/Sperry	Gyrosyn Compass Indicator	737
2587335-11	Honeywell/Sperry	Vertical Gyro	737
2587335-111	Honeywell/Sperry	Vertical Gyro	737
2587335-112	Honeywell/Sperry	Vertical Gyro	737
2587335-113	Honeywell/Sperry	Vertical Gyro	737

2587335-12	Honeywell/Sperry	Vertical Gyro	737
2588282-655	Honeywell/Sperry	Gyrosyn Compass Indicator	737
2588282-657	Honeywell/Sperry	Gyrosyn Compass Indicator	737
2588302-1	Honeywell/Sperry	Directional Gyro	737
2588302-3	Honeywell/Sperry	Directional Gyro	737
2588302-4	Honeywell/Sperry	Directional Gyro	737
2588302-5	Honeywell/Sperry	Directional Gyro	737
2588369-903	Honeywell/Sperry	Attitude Director Indicator	737
2588369-905	Honeywell/Sperry	Attitude Director Indicator	737
2588424-902	Honeywell/Sperry	Rate of Turn Rack	737
2588424-906	Honeywell/Sperry	Rate of Turn Rack	737
2589479-901	Honeywell/Sperry	Roll Control Channel	737
2589479-902	Honeywell/Sperry	Roll Control Channel	737
2CM9ABY7	Ametek/G.E.	Tachometer Generator	737
36140-1AF25B1	Bendix	Radio Magnetic Indicator	737
36140-1AF25B3	Bendix	Radio Magnetic Indicator	737
36140-1AJ25B1	Bendix	Radio Magnetic Indicator	737
36148-1AJ25A1	Bendix	Radio Magnetic Compass Indicator	737
36148-1AJ25A2	Bendix	Radio Magnetic Compass Indicator	737
36154-1AF25A1	Bendix	Radio Magnetic Compass Indicator	737
36154-1AF25B1	Bendix	Radio Magnetic Compass Indicator	737
36154-1AJ25A1	Bendix	Radio Magnetic Compass Indicator	737
36154-1AJ25B1	Bendix	Radio Magnetic Compass Indicator	737
36154-1AJ33B1	Bendix	Radio Magnetic Compass Indicator	737
361551AF25A1	Bendix	Radio Magnetic Compass Indicator	737
36155-1AF25A2	Bendix	Radio Magnetic Compass Indicator	737
36155-1AJ25A1	Bendix	Radio Magnetic Compass Indicator	737
36158-1AF-25-A1	Bendix	Radio Magnetic Compass Indicator	737
36158-1AJ-25B1	Bendix	Radio Magnetic Compass Indicator	737
3800	Thales/Sextant	Chronometric Tachometer	737
391041-023	Simmonds Precision	Compensator Assembly	737
391041-026	Simmonds Precision	Compensator Assembly	737
391041-027	Simmonds Precision	Compensator Assembly	737
393020-003	Simmonds Precision	Fuel Quantity Indicator	737
393020-004	Simmonds Precision	Fuel Quantity Indicator	737
393020-012	Simmonds Precision	Fuel Quantity Indicator	737
393020-01789	Simmonds Precision	Fuel Quantity Indicator	737
393026-001	Simmonds Precision	Fuel Quantity Indicator	737
393026-002	Simmonds Precision	Fuel Quantity Indicator	737
393026-003	Simmonds Precision	Fuel Quantity Indicator	737
393026-01837	Simmonds Precision	Fuel Quantity Indicator	737
393026-01838	Simmonds Precision	Fuel Quantity Indicator	737
393026-01840	Simmonds Precision	Fuel Quantity Indicator	737
393026-01841	Simmonds Precision	Fuel Quantity Indicator	737
393026-01880	Simmonds Precision	Fuel Quantity Indicator	737
393026-03235	Simmonds Precision	Fuel Quantity Indicator	737
393026-052	Simmonds Precision	Fuel Quantity Indicator	737
393026-073	Simmonds Precision	Fuel Quantity Indicator	737
393026-075	Simmonds Precision	Fuel Quantity Indicator	737
393026-077	Simmonds Precision	Fuel Quantity Indicator	737
393026-079	Simmonds Precision	Fuel Quantity Indicator	737
393026-080	Simmonds Precision	Fuel Quantity Indicator	737

393026-081	Simmonds Precision	Fuel Quantity Indicator	737
393026-082	Simmonds Precision	Fuel Quantity Indicator	737
393026-083	Simmonds Precision	Fuel Quantity Indicator	737
393026-084	Simmonds Precision	Fuel Quantity Indicator	737
393026-085	Simmonds Precision	Fuel Quantity Indicator	737
393026-086	Simmonds Precision	Fuel Quantity Indicator	737
393026-087	Simmonds Precision	Fuel Quantity Indicator	737
393026-088	Simmonds Precision	Fuel Quantity Indicator	737
393026-089	Simmonds Precision	Fuel Quantity Indicator	737
393026-091	Simmonds Precision	Fuel Quantity Indicator	737
393026-092	Simmonds Precision	Fuel Quantity Indicator	737
393026-093	Simmonds Precision	Fuel Quantity Indicator	737
393026-094	Simmonds Precision	Fuel Quantity Indicator	737
393026-095	Simmonds Precision	Fuel Quantity Indicator	737
393026-096	Simmonds Precision	Fuel Quantity Indicator	737
393027-002	Simmonds Precision	Fuel Quantity Indicator	737
393080-103	Simmonds Precision	Fuel Quantity Indicator	737
393080-117	Simmonds Precision	Fuel Quantity Indicator	737
393086-01235	Simmonds Precision	Fuel Quantity Indicator	737
4006240	Simmonds Precision	Hydraulic Oil Qty Ind	737
473048	Simmonds Precision	Fuel Summation Unit	737
473383	Simmonds Precision	Fuel Summation Unit	737
522-1859-003	Collins Avionics	Distance Indicator	737
522-1859-033	Collins Avionics	Distance Indicator	737
522-1859-070	Collins Avionics	Distance Indicator	737
522-2782-004	Collins Avionics	Course Indicator	737
522-2782-034	Collins Avionics	Course Indicator	737
522-3120-004	Collins Avionics	Instrument Amplifier	737
522-3122-006	Collins Avionics	Flight Director Indicator	737
522-3122-010	Collins Avionics	Flight Director Indicator	737
522-3138-004	Collins Avionics	Course Indicator	737
522-3342-003	Collins Avionics	Course Indicator	737
522-3342-005	Collins Avionics	Course Indicator	737
522-3487-001	Collins Avionics	Flight Director Indicator	737
522-3487-002	Collins Avionics	Flight Director Indicator	737
522-3487-003	Collins Avionics	Flight Director Indicator	737
522-3487-004	Collins Avionics	Flight Director Indicator	737
522-3867-003	Collins Avionics	Flight Director Indicator	737
522-4063-003	Collins Avionics	Flight Director Indicator	737
522-4114-003	Collins Avionics	Radio Altitude Indicator	737
522-4114-006	Collins Avionics	Radio Altitude Indicator	737
522-4114-008	Collins Avionics	Radio Altitude Indicator	737
522-4363-004	Collins Avionics	Radio Altitude Indicator	737
522-4538-002	Collins Avionics	Aircraft Passenger Address Amplifier	737
522-4825-001	Collins Avionics	Radio Altitude Indicator	737
522-4825-002	Collins Avionics	Radio Altitude Indicator	737
522-4825-004	Collins Avionics	Radio Altitude Indicator	737
522-4825-006	Collins Avionics	Radio Altitude Indicator	737
522-4825-008	Collins Avionics	Radio Altitude Indicator	737
540-2	J.E.T./A.I.M.	Attitude Gyro, Electric, Autopilot	737
60-1321-1	Grimes Aerospace	Emergency Exit Light Power Supply	737
61461	Horizon Aerospace	Dual Fuel Quantity Indicator	737

6212	United Instruments	Manifold Pressure Gauge	737
622-4563-006	Collins Avionics	Radio Altitude Indicator	737
622-4563-008	Collins Avionics	Radio Altitude Indicator	737
64131-760-1	Thales/Sextant	Counter/Pointer Altimeter	737
64141-560-1	Thales/Sextant	Counter/Pointer Altimeter	737
651-12-24-15	Wakmann	Aircraft Clock	737
705-7V4M1	Thales/Sextant	Gyroscopic Horizon	737
705-7V4M1	Thales/Sextant	Gyroscopic Horizon	737
711002-3	Hamilton	Pressure Control Panel	737
711002-4	Hamilton	Pressure Control Panel	737
711002-5	Hamilton	Pressure Control Panel	737
772-5005-001	Collins Avionics	Flight Director Indicator	737
772-5005-005	Collins Avionics	Flight Director Indicator	737
772-5025-001	Collins Avionics	Horizontal Situation Indicator	737
772-5025-013	Collins Avionics	Horizontal Situation Indicator	737
772-5431-001	Collins Avionics	Flight Director Indicator	737
777-1397-003	Collins Avionics	Horizontal Situation Indicator	737
777-1397-004	Collins Avionics	Horizontal Situation Indicator	737
777-1493-001	Collins Avionics	ADF Control Unit	737
777-1493-004	Collins Avionics	ADF Control Unit	737
777-1493-005	Collins Avionics	ADF Control Unit	737
787-6366-002	Collins Avionics	ADF Control Unit	737
787-6366-004	Collins Avionics	ADF Control Unit	737
787-6366-005	Collins Avionics	ADF Control Unit	737
787-6366-009	Collins Avionics	ADF Control Unit	737
787-6385-002	Collins Avionics	Course Indicator	737
787-6385-002	Collins Avionics	Pictorial Navigation System	737
792-6275-003	Collins Avionics	ADF Control Unit	737
792-6275-004	Collins Avionics	ADF Control Unit	737
792-6275-005	Collins Avionics	ADF Control Unit	737
88000-4102	Aerosonic	Aircraft Clock	737
88000-4103	Aerosonic	Aircraft Clock	737
88000-4104	Aerosonic	Aircraft Clock	737
8DJ125LXC3	Ametek/G.E.	Flowmeter Indicator	737
8DJ179KBA2	Ametek/G.E.	Temperature Indicator	737
8DJ179KDA1	Ametek/G.E.	Temperature Indicator	737
8DJ81LXG2	Ametek/G.E.	Tachometer Indicator	737
8DJ81LXH2	Ametek/G.E.	Tachometer Indicator	737
8DJ81LYT2	Ametek/G.E.	Tachometer Indicator	737
8DJ81LYT4	Ametek/G.E.	Tachometer Indicator	737
8DJ81LYV2	Ametek/G.E.	Tachometer Indicator	737
8DJ81LYV4	Ametek/G.E.	Tachometer Indicator	737
8DJ81WAG2	Ametek/G.E.	Tachometer Indicator	737
8DJ81WAG4	Ametek/G.E.	Tachometer Indicator	737
8DJ81WBG4	Ametek/G.E.	Tachometer Indicator	737
8DJ81WBL4	Ametek/G.E.	Tachometer Indicator	737
8DJ81WBM4	Ametek/G.E.	Tachometer Indicator	737
8DJ88GAC1	Ametek/G.E.	Flowmeter Indicator	737
8DJ88LWX3	Ametek/G.E.	Flowmeter Indicator	737
A42899-10-016	Kollsman	Servoed Altimeter	737
A42899-10-216	Kollsman	Servoed Altimeter	737
B0063-81101	Smiths/Astek	Counter Pointer Drum Altimeter	737

B0063-81107	Smiths/Astek	Counter Pointer Drum Altimeter	737
B0063-81108	Smiths/Astek	Counter Pointer Drum Altimeter	737
B0063-81114	Smiths/Astek	Counter Pointer Drum Altimeter	737
B0243-81132	Smiths/Astek	Mach Airspeed Indicator	737
B0247-81107	Smiths/Astek	Mach Airspeed Indicator	737
B0248-81105	Smiths/Astek	Mach Airspeed Indicator	737
B0652-71104-1	Smiths/Astek	Altitude Alerting Control	737
B0704-10004	Smiths/Astek	Overspeed Limit Sensor	737
B0704-10006	Smiths/Astek	Mach Airspeed Warning Switch	737
B0704-10008	Smiths/Astek	Overspeed Limit Sensor	737
B0704-10009	Smiths/Astek	Mach Airspeed Warning Switch	737
B0704-10010	Smiths/Astek	Overspeed Limit Sensor	737
B0704-10011	Smiths/Astek	Mach Airspeed Indicator	737
B0704-10012	Smiths/Astek	Overspeed Limit Sensor	737
B0704-10016	Smiths/Astek	Overspeed Limit Sensor	737
B0704-10037	Smiths/Astek	Overspeed Limit Sensor	737
B0704-10042	Smiths/Astek	Overspeed Limit Sensor	737
B0707-10001	Smiths/Astek	Mach Airspeed Warning Switch	737
B0707-10008	Smiths/Astek	Overspeed Limit Sensor	737
B1800-81103	Smiths/Astek	Servoed Altitude Indicator	737
B1800-81108	Smiths/Astek	Servoed Altitude Indicator	737
B711-1	Simmonds Precision	Hydraulic Oil Qty Ind	737
B712-1	Simmonds Precision	Hydraulic Oil Qty Ind	737
B712-2	Simmonds Precision	Hydraulic Oil Qty Ind	737
B712-4	Simmonds Precision	Hydraulic Oil Qty Ind	737
BPS7-3	Radiant Power Corp	Battery Power Supply	737
C-5C	Ametek/U.S. Gauge	Pilots Standby Compass	737
C-5C	Honeywell/Sperry	Directional Gyro Indicator	737
EA100ANH-153H	Simmonds Precision	Hydraulic Oil Quantity Indicator	737
FDS765A-1	Nohmi	Smoke Sensor	737
FDS765A-2	Nohmi	Smoke Sensor	737
G9325A1	Grimes Aerospace	Navigational Rotating Warning Light	737
G9325A2	Grimes Aerospace	Navigational Rotating Warning Light	737
H321AAM1	Thales/Sextant	Gyroscopic Horizon	737
H321ABM1	Thales/Sextant	Gyroscopic Horizon	737
H321ACM1	Thales/Sextant	Gyroscopic Horizon	737
H321AFM1	Thales/Sextant	Gyroscopic Horizon	737
H321AGM1	Thales/Sextant	Gyroscopic Horizon	737
H321AKM1	Thales/Sextant	Gyroscopic Horizon	737
H321AMM1	Thales/Sextant	Gyroscopic Horizon	737
H321ANM1	Thales/Sextant	Gyroscopic Horizon	737
H321AQM1	Thales/Sextant	Gyroscopic Horizon	737
H321ASM1	Thales/Sextant	Gyroscopic Horizon	737
H321AYM1	Thales/Sextant	Gyroscopic Horizon	737
H321AZM1	Thales/Sextant	Gyroscopic Horizon	737
H321BAM1	Thales/Sextant	Gyroscopic Horizon	737
H321BDM1	Thales/Sextant	Gyroscopic Horizon	737
H321BEM2	Thales/Sextant	Gyroscopic Horizon	737
H321BFM2	Thales/Sextant	Gyroscopic Horizon	737
H321BGM1	Thales/Sextant	Gyroscopic Horizon	737
H321BNM	Thales/Sextant	Gyroscopic Horizon	737
H321CCM	Thales/Sextant	Gyroscopic Horizon	737

JG298A5	Honeywell/Sperry	Pressure Ratio Indicator	737
LK-35-3	TKK	Standby Altimeter	737
LK-35-4	TKK	Standby Altimeter	737
SLZ9123	Avionic Specialties	Inertial-Lead Vertical Speed Indicator	737
SLZ9145	Avionic Specialties	Inertial-Lead Vertical Speed Indicator	737
SLZ9190	Avionic Specialties	Inertial-Lead Vertical Speed Indicator	737
SRDL-6D	Ametek/U.S. Gauge	Dual Indicator	737
SRDL-7G	Ametek/U.S. Gauge	Dual Indicator	737
SRDL-7H	Ametek/U.S. Gauge	Hydraulic System Pressure Indicator, Dual	737
ST-106AB	Ametek/U.S. Gauge	Pressure Transmitter	737
ST-107R	Ametek/U.S. Gauge	Transmitter, Pressure, Hydraulic	737
ST-7R	Ametek/U.S. Gauge	Pressure Transmitter	737
WL1103AM/MS/2	Smiths Industries	Servo Altimeter	737
WL1103AM/MS/3	Smiths Industries	Servo Altimeter	737
WL/202EED3	Smiths Industries	Temperature Indicator	737
WL/202EED4	Smiths Industries	Temperature Indicator	737
WL/504CUF/EA/1	Smiths Industries	Altitude Alerting Unit	737
WL/509CUF/EA/1	Smiths Industries	Altitude Alerting Unit	737
WL/804AM/CP/1	Smiths Industries	Mechanical Counter-Pointer Altimeter	737
WL/808AM/EA/2	Smiths Industries	Mechanical Counter-Pointer Altimeter	737
WL101EED2	Smiths Industries	N1% RPM Indicator	737
WL101EED3	Smiths Industries	N1% RPM Indicator	737
WL102AMS1	Smiths Industries	Altimeter/Airspeed Indicator	737
WL102AMS2	Smiths Industries	Altimeter/Airspeed Indicator	737
WL102AMS3	Smiths Industries	Altimeter/Airspeed Indicator	737

