



# CLAM<sup>®</sup>

Aqueous Parts Cleaning Systems  
*Saving time, money and the environment.*

## INSTALLATION, OPERATION, MAINTENANCE, AND REPAIR MANUAL


**Serial No.:** 2022772



MODELS: C50EBL22



*“Nothing Cleans Like The CLAM!”<sup>®</sup>*



# GENERAL TABLE OF CONTENTS 0.0

*Introduction*.....1.0

*Installation*.....2.0

*Operation* .....3.0

*Maintenance*.....4.0

*Repair* .....5.0

*Parts*.....6.0

*Bulletins*.....7.0

*Options/Accessories*.....8.0



*“Nothing Cleans Like The CLAM!”*®

# introduction

## CONTENTS

1.1E

|   |      |
|---|------|
| <i>Front View</i> .....                 | 1.2  |
| <i>Left Side View</i> .....             | 1.3  |
| <i>Right Side View</i> .....            | 1.4  |
| <i>Rear View</i> .....                  | 1.5  |
| <i>Inside View Upper Section</i> .....  | 1.6  |
| <i>Inside View Lower Section</i> .....  | 1.7  |
| <i>Inside View Electrical Box</i> ..... | 1.8  |
| <i>System Specifications</i> .....      | 1.9  |
| <i>System Warranty</i> .....            | 1.10 |



*“Nothing Cleans Like The CLAM!”*®

# introduction

## SYSTEM COMPONENTS

1.2




front view



# *introduction*

## SYSTEM COMPONENTS

1.3




left side view

# *introduction*

## SYSTEM COMPONENTS

1.4




right side view

# introduction

## SYSTEM COMPONENTS

1.5




rear view

# *introduction*

SYSTEM COMPONENTS

1.6



**UPPER SECTION**  
**LOWER SECTION**

100-102E 9/20

# *introduction*

## SYSTEM COMPONENTS

1.7




inside view  
lower section

# introduction

## SYSTEM COMPONENTS

1.8



(SEE ELECTRICAL DRAWING FOR FULL DETAILS IN THIS MANUAL)

## inside view electrical box

100-109 9/20

© Copyright CLAM