

CLAM[®]

Aqueous Parts Cleaning Systems

Saving time, money and the environment.

INSTALLATION, OPERATION, MAINTENANCE, AND REPAIR MANUAL

Serial No.: 2020100




MODELS:

C150E, C250E, C350E, F200H



“Nothing Cleans Like The CLAM!”[®]



GENERAL TABLE OF CONTENTS 0.0

Introduction.....1.0

Installation.....2.0

Operation3.0

Maintenance.....4.0

Repair5.0

Parts.....6.0

Bulletins.....7.0

Options/Accessories.....8.0



“Nothing Cleans Like The CLAM!”®

introduction

CONTENTS

1.1E

<i>Front View</i>	1.2
<i>Left Side View</i>	1.3
<i>Right Side View</i>	1.4
<i>Rear View</i>	1.5
<i>Inside View Upper Section</i>	1.6
<i>Inside View Lower Section</i>	1.7
<i>Inside View Electrical Box</i>	1.8
<i>System Specifications</i>	1.9
<i>System Warranty</i>	1.10



“Nothing Cleans Like The CLAM!”®

introduction

SYSTEM COMPONENTS

1.2

POWDER COAT
FINISH



HOOD CONTROL BUTTONS
(C250E/C350E/F200 ONLY)

CYCLE CONTROL
SWITCHES

CYCLE TIMER

HEATER INDICATOR
LAMPS

HEATER CONTROL
SWITCH

LOW WATER
WARNING LIGHT


HOOD IN MOTION
WARNING HORN
(C250E/C350E/F200 ONLY)

front view

introduction

SYSTEM COMPONENTS

1.3




F200 MODEL HAS HYDRALIC PUMP THIS SIDE

left side view

introduction

SYSTEM COMPONENTS

1.4




right side view

introduction

SYSTEM COMPONENTS

1.5



rear view

introduction

SYSTEM COMPONENTS

1.6



UPPER
MANIFOLD

UPPER
MANIFOLD HOSE

SIDE MANIFOLD



TURNTABLE

SOLUTION COVER

FILTER (

inside view
upper section

introduction

SYSTEM COMPONENTS

1.7




inside view
lower section

introduction

SYSTEM COMPONENTS

1.8



inside view electrical box