


BC- RESET CIRCUIT BREAKER - BC ROASTERS

In the event your roaster powers off completely you will likely just need to **reset the circuit breaker**. The circuit breaker is found inside the electric room on roaster. On the BC-3 thru 5 you may be able to reach breaker through the utility door on back left side of roaster where the drum speed control module is located. In that case simply unplug roaster and make sure it is turned off at control panel open utility door (The new BC-1 & 2 have breaker on outside of roaster)

SAMPLE ELECTRIC PANEL (ELECTRIC MODEL)



1.SOLID-STATE RELAY 2.UK TERMINALS

3.BUILT-IN CIRCUIT BREAKER* (IF MACHINE WILL NOT POWER ON PLEASE UNPLUG UNIT & OPEN ELECTRIC ROOM AND FLIP ON BREAKER. A SMALL TRIP BUTTON MAY NEED PUSHED TO TRIP ON BEAKER)**

4.FUSE HOLDER 5.TIME RELAY

6.SOLID-STATE RELAY