

## Elev8 Pop Up Parties

### OPERATING INSTRUCTIONS FOR SAFE USE OF EQUIPMENT

- The person or company hiring the inflatable and equipment are fully responsible for the safe operation of the inflatable and any other equipment provided and should ensure the following.
- A responsible adult (21+) must always supervise the inflatable and any other equipment to ensure structure integrity and safety. The inflatable and any / or other equipment must have constant supervision by an adult who is of clear mind and not under the influence of alcohol or any other mind-altering drugs.
- To admit users to the inflatable in a safe manner. To restrict maximum number of users at any one time to the design number for the inflatable in use.
- No use of silly string, paint, glitter bombs, smoke bombs, etc. are permitted. No pets, toys or sharp objects allowed inside or around the inflatable unit. No glass containers / bottles inside or around the inflatable. Any damage to the inflatable unit and contents within will be billed directly to the customer, equal to the value to repair or replace the equipment.
- **PLEASE DO NOT** sit on or touch any electronic equipment if it is not designed for it at any time. Please no food/drinks are to be set on any of the electronic equipment if it is not designed for it. We offer tables, chairs and sitting cubes that can be utilized for this purpose.
- **ABSOLUTELY NO** smoking inside or around the inflatable unit, barbeques or gas / electric heaters within 10 feet of the inflatable unless signed in contract between the Lessor and Lessee. Special circumstances can warrant the use of Electric/ Gas heaters such as cold weather events.
- In the event of rain, users may experience some dripping. This is because the inflatables are made from a breathable material, however, these drips will be very light and will not cause major disruption to the party or event.
- **Please leave the inflatables running at all times, even during light rain.** However, it is strongly recommended that the inflatable should not be used in high winds, heavy rain, thunderstorms, or lightning. **Please only remove the electronic equipment and switch off the inflatable during extreme conditions.** It is extremely important that Elev8 Pop Up Parties be contacted immediately by texting or calling 1-704-778-5826 before this takes place and notify them of the occurrence.
- After rain showers, please re-plug in the inflatable blower - any wetness including bubbling (which is normal) can be dried with the aid of a towel.

- Add-ons such as Bluetooth speakers, disco lights, smoke machines, and backdrops should not be removed or moved by anyone other than the Lessee and only in inclement weather or emergency conditions. Equipment may get hot and is placed to ensure users cannot cause harm to themselves or the structure.
- **BLOWER:** In the event that a blower stops working please ensure users exit the inflatable immediately. Make sure that the blower/blower's tube has not come undone, the deflation zippers are still closed and that nothing is obstructing the blower. In the event that the blower/blowers lose power check your fuse board. If the blowers do not restart, contact us straight away by calling/texting 1-704-778-5826
- **INSURANCE:** Elev8 Pop Up Parties is NOT responsible for any accidents resulting from the use of the inflatable or equipment provided It is the Lessee's responsibility to ensure that their own independent public liability insurance cover is in place for persons while using the inflatable or equipment

I HEREBY AGREE TO ABIDE BY THE TERMS AND CONDITIONS LISTED ABOVE AND AGREE TO HIRE EQUIPMENT LISTED BELOW WHICH IS SUBJECT TO THE LISTED TERMS AND CONDITIONS AS ABOVE. ALL EQUIPMENT WILL BE RETURNED IN THE SAME CONDITION AS THE START OF HIRE.

Full Name \_\_\_\_\_ Signature \_\_\_\_\_ Date: \_\_\_\_\_